







Part 1

Platform use



Part 2

Image drawing



Part 3

Camera screen display



Part 4

Motor and Servo





ェ

P

R



ONE.


Platform Use







https://pi.cocorobo.hk/









更新日誌 📃 🏻 幫助 🕜 CocoBlockly Pi

Platform Use 02 **Auxiliary Area** File Access Area CocoBlockly Pi 保存 🕻 📋 🖸 未命名 邏輯 **□** ± ↔ Python 程式碼 終端交互窗 序列埠數據... 循環 數學運算 變量 字串 陣列 字典 Code/ Interaction Area **Block Programming** 元組 Area 集合 函數 文件 時間 序列埠通訊 基礎硬件 媒體處理 -(0) 人工智能 **Upload Area ?** ① 設備 Block Command Area 物聯網 模組未連接, 請運接 擴展模組 添加設備 連接設備

CocoRobo LTD © 2023 版權所有

☑ 運行


















Use a Type-C cable to connect the Cocopi module to the computer





Platform Use










02

Platform Use







C

ェ

P

刀



TWO.


Image Drawing



Screen

Blank


Create a canvas



Draw and display










Observe the program on the left and talk about what it consists of.





- 1 Screen setup
- Canvas
- Repeat





The role of the canvas



Original screen image

The figure drawn by canvas 1 is



The figure drawn on canvas 2 is









Move multiple shapes on the same canvas together





Resize multiple graphics on the same canvas together






Clear multiple shapes on the same canvas together



Activity 1: Draw a solid square in the middle of the screen with a size of 50*50 pixels and make it green colour

On-screen introduction






Activity 1:

Draw a solid square in the middle of the screen with a size of 50*50 pixels and make it green colour

Process analysis







Activity 1: Draw a solid square in the middle of the screen with a size of 50*50 pixels and make it green colour

Usage of Block Codes

Loops

Screen

On Canvas canvas Draw Filled Rectangle
Set Start Coordinate:

Set End Coordinate:

Create Blank Canvas: Canvas Size: Width 320 Height 240

X: 0 Y: 0

LCD Screen Setup
Show Canvas canvas Canvas


Show Canvas canvas

Repeat forever



Activity 1: Draw a solid square in the middle of the screen with a size of 50*50 pixels and make it green colour

Block **Explanation**








Draw a solid square in the middle of the screen with a Activity 1: size of 50*50 pixels and make it green colour

System Reference








Try to finish drawing the following graphic on the screen:









Activity 1 (Bonus)

Try to finish drawing the following graphic on the screen:

Reference Ideas





ס

刀



THREE.

Camera Screen Display





Activity 2: Take a picture and keep it on the screen

Effect








Activity 2: Take a picture and keep it on the screen

Process analysis






Get the Image Captured from Camera



Activity 2: Take a picture and keep it on the screen

Blocks Used








Activity 2: Take a picture and keep it on the screen

Block Assembly







Activity 3: Continuing from Activity 2, press the C button to complete the photo storage function






Activity 3:

Continuing from Activity 2, press the C button to complete the photo storage function

Block Sequence





Activity 3: Continuing from Activity 2, press the C button to complete the photo storage function

Blocks Used

Screen








Camera







Basic

When Button A is Pressed

Image Process

Set Canvas canvas Saved to Local Path: 1000 Iron

/root/user/img/saved.jpg





Activity 3: Continuing from Activity 2, press the C button to complete the photo storage function

Block **Explanation**

Set Canvas Canvas Saved to Local Path: (/root/user/img/saved.jpg) //root/user/img/

File path Note that the pictures are placed under the user folder.








Continuing from Activity 2, press the C button to complete the photo storage function

Block Reference





ェ

P

刀





FOUR.

Motor and Servo



Meet TT Motors






TT motor, also known as electric motor, is an electrical equipment that converts electrical energy into kinetic energy and is used to drive other devices.



Meet TT Motors

DC reducer motor also known as a gear reducer motor, is composed of an ordinary DC motor and a supporting gear reducer.

The function of the gear reducer is to reduce the speed and increase the torque to provide strong power.





Meet TT Motors

Rated voltage: 4.5-6V

No-load speed: 90±10rpm (depending on the reduction ratio)

Load Current: 190mA (250mA max)

Maximum torque: 0.8Kg·cm

Wire length: 15cm

TT motor is a DC reducer motor and can be used in DIY
scenarios with speed and torque requirements, the speed can be
adjusted which can recognize forward and reverse rotation with
low noise.







Instruction Description

Power

Block Icon	Introduction
Motor Driver Setup	Initializes the TT motor
Set Motor M1 → 's Speed to 150 (0~255) Rotating Clockwise → turns	Set the specified number for the TT motor to rotate at a certain speed/direction




Power on the Motor



Activity 1: Rotate the TT motor clockwise at a speed of 50.

Connect the module to the TT motor



Use blocks



Set Motor M1 ☐ 's Speed to 150 (0~255) Rotating Clockwise ☐ turns





Activity 1: Rotate the TT motor clockwise at a speed of 50.

Block Reference







Servo Motor 33

A servo motor is a motor that acts according to commands.

The servo motor can recognize its position and control its action speed.















圖源: https://learn.thestempedia.com/wp-content/uploads/2018/05/Servo-Motor.jpg





The position detector (angle sensor) is its input sensor, and the resistance value of the position detector will change the position of the servo motor rotation. By reading the resistance value in the control circuit, the speed and direction of the motor can be adjusted appropriately according to the resistance value, so that the motor rotates at a specified angle. This enables precise rotation control of the servo motor.



Combine the servo motor with either servo motor arm.

What is the maximum angle range of the servo motor that is turned by the rudder arm?















Use a Type C Cable to connect the module to the computer






Activity 2: Control the servo motor to rotate between 0 and 90 degrees.

Block Explanation

Power









Activity 2: Control the servo motor to rotate between 0 and 90 degrees.

Block Reference

